


# SILENT DISCO SETUP INSTRUCTIONS



SILENTBEATS.CO.UK

SILENT DISCO HIRE




## The Transmitters

- Straighten the aerial
- Plug the power cable into the power input
- Plug the audio cables into the audio input, matching the colours
- Plug the audio jack into your chosen device or adaptor

## Channel Selection

- You **MUST** ensure each transmitter is set to a separate channel
- You will require a separate music device for each transmitter
- Press the channel button to select channels 1, 2 or 3



## Headphone Setup

- Power on the headphones using the power switch and wait for them to illuminate
- Use the channel selection switch to connect to the desired transmitter channel
- Press play on your chosen device
- Use the volume control to adjust the sound for each individual headphone

Now Let's party!!



Check out the video tutorial at [SilentBeats.co.uk](https://www.silentbeats.co.uk) - How it works

# PACKING AWAY INSTRUCTIONS



SILENTBEATS.CO.UK

SILENT DISCO HIRE



## Packing Away

- Locate the 'Packing Away' pack, which contains the return labels and security tags
- Please ensure you return all the equipment to the crate and repack the same way it was received

## Attach Security Tags

- You **MUST** ensure you secure the crate with the two security tags provided
- All of our crates are fitted with trackers for added security



## Headphone Setup

- Attach the collection notice provided to the lid of the crate
- DPD will collect between 9.00am and 5.30pm the day after your event
- We will check the booking has been returned correctly and then notify you

Thank You!



Check out the video tutorial at [SilentBeats.co.uk](https://www.silentbeats.co.uk) - How it works